ZSW monitoring functions 2
r2198

Bit No.	Status word monitoring 2	
0	**Reserved**	
1	**Reserved**	
2	**Reserved**	
3	**Reserved**	
4	**1 = |n_set| < p2161**	r2198.4
5	**1 = n_set ≥0**	r2198.5
6	**1 = Motor blocked**	r2198.6
7	**1 = Motor stalled**	r2198.7
8	**Reserved**	
9	**Reserved**	
10	**1 = Torque setpoint < torque threshold value 1 (p2174)**	r2198.10
11	**1 = Load monitoring signals an alarm**	r2198.11
12	**1 = Load monitoring signals a fault**	r2198.12
13	**Reserved**	
14	**Reserved**	
15	**Reserved**	

<1> From speed signals [8010.8] → 4

<1> From speed signals [8010.8] → 5

From torque messages, motor locked/stalled [8012.8] → 6

From torque messages, motor locked/stalled [8012.8] → 7

From torque messages, motor locked/stalled [8012.3] → 10

From load monitoring [8013.8] → 11

From load monitoring [8013.8] → 12

<1> Only relevant if the function module "extended signals/
monitoring functions" (r0108.17 = 1) is active.

1	2	3	4	5	6	7	8