



NOTE: THE LETTERS NEXT TO THE TERMINAL STUDS ARE FOR PURPOSES OF DIMENSIONAL LOCATION ONLY. FOR CONNECTIONS, SEE THE APPROPRIATE EXTERNAL CONNECTION DIAGRAM.

INSTRUMENT	STUD	DIMENSIONS			
INSTROMENT	LOCATION	x	Y		
Type DB-10 Ammeter	CD	3 15/32"	2 31/32"		
Type DB-10 Voltmeter	AB	3 15/32"	2 31/32"		
Type DB-10 Ground Detector	CD	3 15/32"	2 31/32"		
Type AB-10 Ammeter	AB	4 3/8"	3 7/8"		
Type AB-10 Voltmeter	AB	4 3/8"	3 7/8"		





 $3\frac{3I''}{32} DIA \rightarrow$ NOTE: THE LETTERS NEXT TO THE TERMINAL STUDS ARE FOR PURPOSES OF DIMENSIONAL LOCATION ONLY FOR CONNECTIONS, SEE THE APPROPRIATE EXTERNAL CONNECTION DIAGRAM

BACK

FIG. 2. DIMENSIONS OF TYPES AB-12 AND -13, AND TYPES DB-12 AND -10 AMMETERS, VOLTMETERS AND GROUND DETECTORS.

INSTRUMENT	STUD	DIMENSIONS			
INSTRUMENT	LOCATION	×	Y		
D-c Ammeters	CD	3 1/2"	2 31/32"		
D-c Voltmeters	AB	3 1/2"	2 31/32"		
D-c Ground Detector	CD	3 1/2"	2 31/32"		
A-c Ammeters	AB	4 13/32"	3 7/8"		
A-c Voltmeters	AB	4 13/32"	3 7/8"		

Fig. 2. Dimensions of Types AB-12 and -13, and Types DB-12 and -13 ammeters, voltmeters, and ground detectors.

TYPES

AB-10,-12,-13,-14,-15,-16,-18, AND -19* AND DB-10,-12,-13,-14,-15,-16,-18, AND -19* AMMETERS AND VOLTMETERS

INTRODUCTION

These instructions cover the installation of the General Electric Types AB and Types DB a-c and d-c ammeters and voltmeters. These instruments are long-scale, rectangular-pattern, switchboard types designed for flush mounting. The instruments, as supplied, are intended for use on the circuit specified by the customer.

There is a nameplate located on the back of each instrument. This nameplate gives the serial number and such information on the current or voltage rating, frequency rating, transformer ratio, full-scale value, and lead resistance as is applicable to the instrument. On voltmeters, the nameplate also indicates whether the resistor is internal or external.

Ammeters and voltmeters supplied with transformers will have their scales calibrated in primary amperes or primary volts respectively, unless otherwise specified.

A-C AMMETERS

When the circuit exceeds 20 amperes, a current transformer of the ratio indicated on the nameplate must be used. When the circuit exceeds 650 volts a current transformer must be used for purposes of in-

* Discontinued type; no longer available

sulation. The current transformer must have a frequency rating which corresponds to that indicated on the instrument nameplate.

A-C VOLTMETERS

When the circuit exceeds 750 volts, a potential transformer of the ratio indicated on the instrument nameplate must be used. The transformer must have a frequency rating which corresponds to that on the instrument nameplate.

An external Form-3 resistor must be used when so indicated on the instrument nameplate. The table below gives the number of tubes in the resistor supplied with instruments of various voltage ratings. When an external resistor is used, it must bear the same serial number as that of the instrument. The

EXTERNAL RESISTORS				
Description	Volts	External Resistor		
Single-range	150	None		
Single-range	175, 300	One 1-tube		
Single-range	350	One 1-tube or		
		2-tube		
Single-range	500	One 4-tube or		
		2-tube		
Single-range	600, 750	One 4-tube		
Double-range	75/150	None		
Double-range	150/300	One 1-tube		

			BURDEN D	ATA			
TYPE	Impedance in Ohms	Effective Resistance in Ohms	Inductance in Henries	Volt-amperes	Watts	Vars	Power Factor
		120	-volt, 60-cycle Pote	ential Circuit			
Voltmeters (150-volt rating)	3020	2960	1.52	4.76	4.67	0.94	0.98
		5-0	mpere, 60-cycle Cu	rrent Circuit			
Ammeters	0.086	0.05	0.000187	2.15	1.25	1.78	0.58

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

dimensions of the external resistors are given in Fig. 10, 11, and 12.

D-C AMMETERS

D-c ammeters designed for current measurement above 60 amperes necessitate the use of shunts which are to be connected to the ammeter by means of the leads provided. In the event that leads are supplied by the purchaser, their resistance should agree with the value stamped on the instrument nameplate. Any change in the resistance of these leads will introduce an error in the reading. General Electric shunts of the same ampere rating and millivolt drop are interchangeable.

Warning: All ammeter shunts should be connected in the grounded side of the line when possible. When this is not possible, or the circuit cannot be grounded, the metal parts of manually operated contact devices or auxiliary pointer knobs which project through the cover are at line potential. When the cover is removed, also remember that the instrument windings, as well as the scale and pointer, are at line potential. Use caution to avoid contacting this potential.

As the resistance of the shunt leads used in certain applications cannot be predetermined at the factory, it has been found desirable to furnish some d-c ammeters with an internal rheostat to adjust for nonstandard lead resistances.

The nameplate on the instrument has an INSTRU-MENT + LEAD RESIS. value stamped upon it. This value is to be that of the total circuit, which is considered to include the resistance of the instrument and its leads with the shunt disconnected. This total circuit resistance must be adjusted correctly in order to attain the specified accuracy of the instrument.

To adjust the rheostat for a given lead resistance, proceed as follows:

If a resistance bridge is available, connect it across the shunt end of the leads (shunt disconnected) and the instrument across the opposite end. Set the resistance bridge for the INSTRUMENT + LEAD RESIS. value stamped on the instrument nameplate. Loosen the lock nut (located under the nameplate), and turn the rheostat shaft (which projects through the nameplate) until a zero deflection is secured on the bridge galvanometer. After the correct setting has been obtained, retighten the lock nut.

If a resistance bridge is not available, adjustment may be made by connecting a standard millivoltmeter across the shunt end of the leads (shunt disconnected) and the instrument across the opposite end. Apply a low adjustable d-c voltage across the shunt end of the leads and adjust this voltage until the indication on the standard millivoltmeter agrees with the fullscale millivolts (marked FULL SCALE MV) on the instrument nameplate. Loosen the lock nut (located under the nameplate), and turn the rheostat shaft (which projects through the nameplate) until the ammeter reads full scale. Retighten the lock nut.

Note: The maximum lead resistance is about 1 ohm for a 100-millivolt instrument and about 0.26 ohm for a 50-millivolt instrument.

5

€

D-C VOLTMETERS

D-c voltmeters designed for use on circuits above 750 volts and d-c ground detectors for voltages up to and including 750 volts are furnished with external resistors and are connected directly to the circuit to be measured.

INSTALLATION

MOUNTING

The appropriate dimension drawings shown in this book should be followed when drilling the switchboard. All drilling and all wiring on the switchboard should be completed before mounting the instruments. Supporting studs are provided for mounting on the switchboard. Mount the instruments in a level position.

These instruments are practically uneffected by stray fields, but it is advisable to keep transformers and wires carrying heavy current as far as possible from all indicating instruments.

When there is no current flowing through the instrument and it is properly leveled, the pointer should indicate zero. Any deviation from zero should be corrected by means of the zero adjustor.

TERMINAL CONNECTIONS

The threads on the terminal studs and nuts should be clean and bright. The contact surfaces of nuts, busbars, and cable terminals must be thoroughly clean to insure good contact. If a nut turns hard, it should be run over a tap of the proper dimensions; otherwise, the threads on the stud may be ruined or the stud turned in the instrument, thereby breaking the connection. After the instrument has been connected, tighten the nuts sufficiently to insure good contact. Do not overtighten.

The nuts and studs used in these instruments are U. S. standard.

Connect the instrument as shown in the appropriate diagram. The numbers in these connection diagrams correspond to the numbers stamped on the instrument terminals.

On instruments manufactured prior to 1951, the terminal studs are stamped with letters instead of numbers. For such instruments, the connection diagrams in this book may be followed by observing the pictorial positioning of the terminals, rather than the stud markings.

Warning: Care must be exercised in handling high tension wires when installing instruments on such circuits.

POLARITY MARKINGS OF TRANSFORMERS

Transformers of present manufacture have polarity markings of white paint or markers, H_1 for primary and X_1 for secondary, on or near the proper terminal. These markings denote the relative polarity and facilitate the making of proper connections for correct direction of deflection of instruments. The relation of the marked leads is such that instantaneous direction of the current in them is the same; namely, toward the transformer in the marked primary lead and from the transformer in the marked secondary lead, or vice versa. These polarity markings are indicated in the connection diagrams and should be followed irrespective of their physical location on the transformers.

GROUNDING CASES OF A-C INSTRUMENTS

It is frequently desirable to use transformers on circuits of over 150 volts. The cases of instruments which are used with current and potential transformers should be connected to the grounded side of the secondary circuits of such transformers. No. 12 Awg copper wire is suitable for this purpose.

Grounding connections from the grounded side of the secondary circuits to earth should be made in accordance with the provisions of the National Electric Code.

PRINCIPLES OF OPERATION

The d-c instruments utilize a permanent-magnet, moving-coil mechanism adapted for the longscale instrument design. Current passing through the moving coil produces a magnetic field which interacts with the field produced by the permanent magnet, thus supplying the deflecting torque. The moving system deflects until counterbalanced by the instrument control springs.

The a-c instruments (except expanded-scale voltmeters) employ a moving iron mechanism of the attraction-repulsion type. In these instruments, three soft-iron strips of carefully determined configuration are mounted inside the field coil.

When this coil is energized, it magnetizes the three iron strips and also a vane attached to the pivoted shaft. The center iron strip exerts a force of repulsion, and the other two strips a force of attraction, on the moving vane, in such a manner that the pointer moves upscale until the torque is counterbalanced by the instrument control spring.

The expanded-scale, a-c voltmeters utilize a standard electrodynamometer mechanism with a saturable reactor placed in series with the moving coil. The moving-coil circuit is connected in parallel with a circuit consisting of the field and frequency compensating network.

When the voltage source is applied across the saturable reactor, the exciting current varies in a nonlinear fashion with the voltage. The scale distribution corresponds to this nonlinear variation, and the instrument produces an accurate, readable indication in the area of the reference voltage.






Fig. 3. Dimensions of Types DB-12 and -13 ammeters with rheostat for lead-length compensation.







* PRESENT ONLY ON A-C VOLTMETERS (EXCEPT EXPANDED SCALE) RATED 150 VOLTS OR BELOW


AT 50% FINAL SIZE

NOTE: THE LETTERS NEXT TO THE TERMINAL STUDS ARE FOR PURPOSES OF DIMENSIONAL LOCATION ONLY, FOR CONNECTIONS, SEE THE APPROPRIATE EXTERNAL CONNECTION DIAGRAM


F1G.4.	DIMENSIONS	OF TYPES AB-14, -1	5, AND -19 AN	D TYPES	
DB-14,	-15, AND -19	AMMETERS, VOLTM	ETERS, AND	GROUND	DETECTORS.


INSTRUMENT	STUD	DIMENSIONS			
INSTROMENT	LOCATION	x	Y		
D-c Ammeters	CD	3 9/16"	2 31/32"		
D-c Voltmeters	AB	3 9/16"	2 31/32"		
D-c Ground Detector	CD	3 9/16"	2 31/32"		
A-c Ammeters	AB	4 15/32"	3 7/B"		
A-c Voltmeters	AB	4 15/32"	3 7/8"		
A-c Voltmeters (expanded-scale)	AB	5 29/32"	5 5/16"		

Fig. 4. Dimensions of Types AB-14, -15, and -19 and Types DB-14, -15, and -19 ammeters, and voltmeters, and ground detectors









васк

NOTE: THE LETTERS NEXT TO THE TERMINAL STUDS ARE FOR PURPOSES OF DIMENSIONAL LOCATION ONLY. FOR CONNECTIONS, SEE THE APPROPRIATE EXTERNAL CONNECTION DIAGRAM.

* PRESENT ONLY ON A-C VOLTMETERS (EXCEPT EXPANDED SCALE) RATED 150 VOLTS OR BELOW

INSTRUMENT	STUD	DIMENSIONS			
INSTROMENT	LOCATION	x	Y		
D-c Ammeter	CD	3 5/16"	2 27/32"		
D-c Voltmeter	AB	3 5/16"	2 27/32"		
D-c Ground Detector	CD	3 5/16"	2 27/32"		
A-c Ammeter	AB	4 7/32"	3 3/4"		
A-c Ammeter (double-rated)	AB EF	4 7/32''	3 3/4"		
A-c Voltmeter	AB	4 7/32"	3 3/4"		
A-c Voltmeter (expanded-scale)	AB	5 21/32"	3 3/16"		

Fig. 6. Dimensions of Types AB-16 and DB-16 ammeters, voltmeters, and ground detectors.






Fig. 7. Dimensions of Type DB-16 ammeters with rheostat for lead-length compensation.







NOTE: THE LETTERS NEXT TO THE TERMINAL STUDS ARE FOR PURPOSES OF DIMENSIONAL LOCATION ONLY. FOR CONNECTIONS, SEE THE APPROPRIATE EXTERNAL CONNECTION DIAGRAM.



	STUD	DIMENSIONS			
INSTRUMENT	LOCATION	x	Y		
D-c Ammeter	CD	3 11/32"	2 31/32"		
D-c Voltmeter	AB	3 11/32"	2 31/32"		
D-c Ground Detector	CD	3 11/32"	2 31/32"		
A-c Ammeter	AB	4 1/4"	3 7/8"		
A-c Ammeter (double-rated)	AB EF	4 1/4"	3 7/8"		
A-c Voltmeter	AB	4 1/4"	3 7/8"		
A-c Voltmater (expanded-scale)	AB	5 11/16"	5 5/16"		

Fig. 8. Dimensions of Types AB-18 and DB-18 ammeters, voltmeters, and ground detectors.




Fig. 9. Dimensions of Type DB-18 ammeters with rheostat for lead-length compensation.

10-32 THD

2

砲






Fig. 11. Two-tube. Form-3 resistor.

2 TUBES

83




Fig. 12. Four-tube, Form-3 resistor.

CONNECTION DIAGRAMS (Back Views)

SOURCE

FUSES




Fig. 13. Self-contained d-c ammeter.

SOURCE

LOAD

1

FUSES

÷




Fig. 14. D-c ammeter with external shunt.




Fig. 15. Low range on double-rated d-c ammeter.




Fig. 16. High range on double-rated d-c ammeter.

SOURCE FUSES EXTERNAL RESISTOR LOAD

Fig. 19a. D-c ground detector for voltages up to and including 750 volts (with external resistor).

9




Fig. 17. Self-contained d-c voltmeter.





Fig. 18. D-c voltmeter rated above 750 volts (with external resistor).



(NOT FURNISHED)

Fig. 19. Double-rated d-c voltmeter (illustrating use of switch to select range).






Fig. 26. A-c voltmeter rated above 150 volts (with external resistor).




Fig. 27. A-cvoltmeter (Types AB-10, -12, and -13 only) with potential transformer.




Fig. 28. A-cvoltmeter (Types AB-14, -15, -16, -18, and -19 only) with potential transformer.


,

	1				DIM	ENSION	S IN IN	CHES				1	Connection
Атр	Fig. No.29	•	в	с	D	E	F	G	н	J	ĸ	L	Strips Each End
75 80 100	9 9 9	6¼ 6¼ 6¼	1 1/8 1 1/4 1 1/2	514 514 514	3 ¹ /16 3 ¹ /16 3 ¹ /16 3 ¹ /16	1/2	222	1 % 1 % 32 1 % 32	13/32 13/32 13/32	1/4 1/4 1/4	1/8 1/8 1/8	1/8 1/8 1/8	1 1 1
150 200 250 300	2 2 2 2	6 14 6 14 6 14 6 14	1 1/2 1 1/2 1 1/2 1 1/2	514 514 514 514	3 ¹¹ /16 3 ¹¹ /16 3 ¹¹ /16 3 ¹¹ /16	11/16 7/8 11/16 1/4	× × ×	$ \begin{array}{r}1^{17}3_{2}\\1^{17}3_{2}\\1^{17}3_{2}\\1^{17}3_{2}\\1^{17}3_{2}\end{array} $	1732 1732 1732 1732	XXXXX	7/32 5/16 13/32 1/2	7/32 5/16 13/32	1 1 1
400 500 600 800	a a a	81/4 81/4 81/4 81/4	1 1/2 1 7/8 2 2 3/8	614 614 614	3 7/8 3 7/8 3 7/8 3 7/8 3 7/8	1 % 1 % 1 % 1 1 3/16 2	1 1 1 1	2 3/16 2 3/16 2 3/16 2 3/16 2 3/16	1732 1732 2132 2132 2132 32	1/8 1/8 1/8	5/8 5/8 23.32 13/16	5/8 5/8 23 13 16	1 1 1
1000 1200 1500 2000	Ե Ե Ե	93/4 10 10 101/2	3 3 3 4	7 % 8 8 8 %	4 % 5 5 5 1/2	$ \begin{array}{r}1^{11}16\\2^{5}16\\2^{5}16\\2^{15}32\end{array} $	1 % 1 % 2 ½	2 1/2 2 1/2 2 1/2 2 1/2 2 1/2	21/32 17/32 17/32 21/32 21/32	15/32 25/32 17/32 39/64	· · · • •	XXXX	2 2 3 3
2500 3000 4000 5000	Ъ Ъ с с	101/2 111/2 111/2 111/2	4 4 5	81/2 91/2 91/2 91/2	51/2 61/2 61/2 61/2	2 ¹⁵ /16 3 °/16 7 7 1/2	2 1/2 2 1/2 4 ²¹ /32 4 1/2	2 1/2 2 1/2 2 3/8 2 5/8	²¹ 82 ²¹ 32 21 5 21 5 21 5	¹⁹ /32 ²⁹ /32	••••• ••••	**	4 4 5 5
6000 8000 10000	с с с	13 % 15 % 17 %	6 6 8	1134 1334 1514	8 ³ /4 10 ³ /4 12 ¹ /4	8 91 <u>6</u> 101 <u>6</u>	4 ²¹ /32 6 ⁷ /32 5 ⁸ /4	2 7/8 3 1/8 3 5/8	33	••••	••••		5 7 7

FORM-15, 50-MILLIVOLT SHUNTS


For current values above 10,000 amp, the best arrangement is to use two or more shunts in parallel with a separate set of leads for each shunt.

The Form-15 shunts for 800 amp and below have single-leaf terminals; above 800 amp, multileaf terminals are provided.





41"

(c) 4,000- to 10,000-amp shunts



Ø





WHEN YOU NEED SERVICE

IF YOU NEED TO REPAIR, recondition, or rebuild any electric apparatus, a G-E service shop near you is available day and night, seven days a week, for work in the shops or on your premises. Latest factory methods and genuine G-E renewal parts are used to maintain the original performance of your G-E equipment. For full information about these services, contact the nearest service shop or sales office listed below:

APPARATUS SERVICE SHOPS

Appleton, Wisc..... Midway Industrial Area, County Trunk, "P" Indus. Blvd. Boston — Medford 55, Mass. Mystic Valley Pkwy. Charleston 28, W. Va., 306 MacCorkle Ave., S.E. Cincinnati 2, Ohio 444 W. Third St. Cleveland 4, Ohio 4966 Woodland Ave. Corpus Christi, Texas . 115 Busse St. Davenport --- Bettendorf, Ia..... 1039 State St. Detroit 2, Mich. 5950 Third Ave. Houston 20, Texas. . 5534 Harvey Wilson Drive Indianapolis 22, Ind. 1740 W. Vermont St. Kansas City 8, Mo. Louisville, Ky. 2014 New Main St. Midland, Tex. 3404 Bankhead Hwy. Milwaukee 3, Wisc...... 940 W. St. Paul Ave. Minneapolis 12, Minn...... 2025 49th Ave., N. Philadelphia 24, Pa. 1040 E. Erie Ave. Pittsburgh 6, Pa. 6519 Penn Ave. Portland 10, Oregon ... 2727 N.W. 29th Ave. Sacramento, Calif. 99 N. 17th St. St. Louis 10, Mo. .1115 East Road Salt Lake City 4, Utah. 301 S. Seventh West St. San Francisco 3, Calif. 1098 Harrison St. Southington, Conn. . 53 Railroad Ave. Spokane 3, Wash. S. 155 Sherman St. Toledo 4, Ohio. 1 So. St. Clair St. Wheeling, W. Va. 2050 National Rd. 54 N. Harrison St. York, Pa.

APPARATUS SALES OFFICES

Abilene, Texas	
Akron 8, Ohio	335 S. Main St.
Albany 7, N. Y.	
	ex. 323 Third St., S.W.
Allentown, Pa	1132 Hamilton St.
Amarillo, Texas	Amarillo Bldg.
Appleton, Wisc.	531 W. College Ave.
Atlanta 3, Ga	1860 Peachtree Rd., N.W.
Augusta, Ga	Masonic Bldg.
Augusta, Me.	
Baltimore 1, Md.	
Bangor, Maine	
Baton Rouge 6, La.	3170 Florida Blvd.
Battle Creek, Mich.	25 W. Michigan Ave.
Beaumont, Texas	1385 Calder Ave.
	m. 816, 303 No. Broadway
Binghamton, N. Y.	19 Chenango St.
Birmingham 3, Ala.	1804 Seventh Ave., N.

	Appalachian Bldg.
Boise Idaha	
	535 Washington St.
	336, 103 N. Wyoming St.
	700 Tuscarawas St., W.
	210 Second St., S.E.
	306 MacCorkle Ave., S.E.
	112 S. Tryon St.
Chattanooga 2, Tenn	
	5970A, 840 S. Canal St.
Cincinnati 2, Ohio	215 W. Third St.
Cleveland 4, Ohio	. 4966 Woodland Ave.
Columbia 1, S.C., P.O.	Box 1434, 1420 Lady St.
	40 S. Third St.
Corpus Christi, Texas	205 N. Chaparral
Dallas 2, Texas	1801 N, Lamar St.
Davenport—Bettendor	f, Ia. 1039 State St.
	11 W. Monument Bldg.
Dayton 9, Ohio Avia.	
	2600 Far Hills Ave.
	. 650 Seventeenth St.
Duluth 2, Minn.	14 W. Superior St.
	in and Woodlawn Aves.
Eugene, Ore	610 High St. 123 N.W. Fourth St.
	310 Jacobs Bldg.,
	P.O. Box 1626
Fergus Falls Minn 1081	N.Court Ave.P.O.Box 197
	653 S. Saginaw St.
	3606 So. Calhoun St.
Fort Worth, Tex.	
	6200 Camp Bowie Blvd.
Fresno 1, Calif.	
	Tulare and Fulton St
	301 S. Elm St.
Greenville, S. C.	108 W. Washington St.
Gulfport, Miss.	207 Jo-Fran Bldg.
	Professional Arts Bldg.
Hartford 5, Conn	
Houston I, lexas	1312 Live Oak St.
	110 N. Illinois St.
	120 W . Michigan Ave.
Jackson I, Miss.	203 W. Capitol St.
Jacksonville 2, Fla.	
	D. Box 548, 2 Second St.
	48, 220 1/2 W. Fourth St.
	.106 W. Fourteenth St.
Lansing 8, Mich. 306 /	Michigan National Tower
	First National Bank Bldg.
	be Bldg., 206 S. 13th St.
	103 W. Capitol Ave.
-	
	3202 Avenue "A"
Manchester, N. H.	

Medford, Ore., P.O. Bo	x 1349, 205 W. Main St.
	8 N. Third St.
	25 S.E. Second Ave.
Midwest City, Okla	
	207 Post Off. Bldg.
Milwaukee 3, Wisc	
Minneapolis 3, Minn.	
Mobile 13, Ala.	
Nashville 3, Tenn	
Newark 2, N. J.	
New Haven 6, Conn.	
New Orleans 12, La.	
New York 22, N. Y.	
New York	Avia. & Def., Fed. Bldg.,
	port, Jamaica 30, N. Y.
Niagara Falls, N. Y	
Norfolk 10, Va.	
	409 Thirteenth St.
Oklahoma City 2, Okla.	
Omaha 2, Nebr.	409 S. Seventeenth St.
Pasco, Wash.	
Philadelphia 2, Pa	1405 Locust St.
Phoenix, Ariz. P.O. Box	4037, 303 Luhrs Tower
Pittsburgh 22, Pa. The	Oliver Bldg., Mellan Sq.
Portland 7, Ore.	920 S.W. Sixth Ave.
Providence 3, R. I.	Industrial Trust Bldg.
Raleigh, N. C.	336 Fayetteville St.
Richmond 17, Va.	
Riverside, Calif.	3570 Ninth St.
Roanoke 16, Va.	920 S. Jefferson St.
	110 S. First St.
	38½ Center St.
	626 Forum Bldg.
	ond National Bank Bldg.
	818 Olive St.
Salt Lake City 9. Utah	200 S. Main St.
San Antonio 5. Texas	434 So. Main Ave.
	1240 Seventh Ave.
	235 Montgomery St.
	460 Park Ave.
Savannah Ga	4 E. Bryan St.
Seattle 4 Wash	710 Second Ave.
Seattle 8 Wash Avia	& Def., 220 Dawson St.
Shrevenort La	910 Shelby Bldg.
Sioux City 13, Iowa 57	2 Orpheum Electric Bldg.
South Bend 1. Ind	112 W. Jefferson Blvd.
	S. 162 Post St.
	607 E. Adams St.
	1387 Main St.
	11 So. San Joaquin St.
	3532 James St.
	1202 Washington Bldg.
Tampa 6, Fla	1202 Washington Bldg. 1206 North A St.
Tampa 6, Fla	1202 Washington Bldg. 1206 North A St. 420 Madison Ave.
Tampa 6, Fla Toledo 4, Ohio Trenton 8, N. J	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St.
Tampa ó, Fla. Toledo 4, Ohio Trenton 8, N. J. Tucson, Ariz. P.O. Boy	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St. 710, 650 N. Sixth Ave.
Tampa ó, Fla. Toledo 4, Ohio Trenton 8, N. J. Tucson, Ariz. P.O. Boy	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St. 710, 650 N. Sixth Ave.
Tampa 6, Fla. Toledo 4, Ohio Trenton 8, N. J. Tucson, Ariz. P.O. Boy Tulsa 3, Okla.	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St.
Tampa 6, Fla. Toledo 4, Ohio Trenton 8, N. J. Tucson, Ariz. P.O. Boy Tulsa 3, Okla. Utica 2, N. Y.	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St. 710, 650 N. Sixth Ave. 320 S. Boston Ave. 258 Genesee St.
Tampa 6, Fla Toledo 4, Ohio Trenton 8, N. J Tucson, Ariz. P.O. Boo Tulsa 3, Okla Utica 2, N. Y Washington 5, D. C	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St. 710, 650 N. Sixth Ave. 320 S. Boston Ave. 258 Genesee St. 777–14th St., N.W.
Tampa 6, Fla. Toledo 4, Ohio Trenton 8, N. J. Tucson, Ariz. P.O. Boo Tulsa 3, Okla. Utica 2, N. Y. Washington 5, D. C. Waterloo, Iowa	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St. 710, 650 N. Sixth Ave. 320 S. Boston Ave. 258 Genesee St. 777–14th St., N.W. 206 W. 4th St.
Tampa 6, Fla.Toledo 4, Ohio.Trenton 8, N. J.Tucson, Ariz.P.O. BooTulsa 3, Okla.Utica 2, N. Y.Washington 5, D. C.Waterloo, IowaWenatchee, Wash.3	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St. 710, 650 N. Sixth Ave. 320 S. Boston Ave. 258 Genesee St. 777–14th St., N.W. 206 W. 4th St. 28 N. Wenatchee Ave.
Tampa 6, Fla.Toledo 4, OhioTrenton 8, N. J.Tucson, Ariz.P.O. BooTulsa 3, Okla.Utica 2, N. Y.Washington 5, D. C.Waterloo, IowaWenatchee, Wash.3Wheeling, W. Va.	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St. 710, 650 N. Sixth Ave. 320 S. Boston Ave. 258 Genesee St. 777–14th St., N.W. 206 W. 4th St. 28 N. Wenatchee Ave. 40 Fourteenth St.
Tampa 6, Fla.Toledo 4, OhioTrenton 8, N. J.Tucson, Ariz.P.O. BooTulsa 3, Okla.Utica 2, N. Y.Washington 5, D. C.Waterloo, IowaWenatchee, Wash.3Wheeling, W. Va.Wichita 2, Kan.	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St. 214 E. Hanover St. 210, 650 N. Sixth Ave. 320 S. Boston Ave. 258 Genesee St. 777–14th St., N.W. 206 W. 4th St. 28 N. Wenatchee Ave. 40 Fourteenth St. 200 E. First St.
Tampa 6, Fla.Toledo 4, OhioTrenton 8, N. J.Tucson, Ariz.P.O. BooTulsa 3, Okla.Utica 2, N. Y.Washington 5, D. C.Waterloo, IowaWenatchee, Wash.Wheeling, W. Va.Wichita 2, Kan.Williamston, N. C.	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St. 710, 650 N. Sixth Ave. 320 S. Boston Ave. 258 Genesee St. 777–14th St., N.W. 206 W. 4th St. 28 N. Wenatchee Ave. 40 Fourteenth St. 200 E. First St. 115 E. Main St.
Tampa 6, Fla.Toledo 4, Ohio.Trenton 8, N. J.Tucson, Ariz.P.O. BooTulsa 3, Okla.Utica 2, N. Y.Washington 5, D. C.Waterloo, Iowa.Wenatchee, Wash.3Wheeling, W. Va.Wichita 2, Kan.Williamston, N. C.Worcester 5, Mass.	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St. 214 E. Hanover St. 210 S. Boston Ave. 258 Genesee St. 777–14th St., N.W. 206 W. 4th St. 28 N. Wenatchee Ave. 40 Fourteenth St. 200 E. First St. 115 E. Main St. 288 Grove St.
Tampa 6, Fla.Toledo 4, OhioTrenton 8, N. J.Tucson, Ariz.P.O. BoyTulsa 3, Okla.Utica 2, N. Y.Washington 5, D. C.Waterloo, IowaWenatchee, Wash.3Wheeling, W. Va.Wichita 2, Kan.Williamston, N. C.Worcester 5, Mass.York, Pa.	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St. 214 E. Hanover St. 210, 650 N. Sixth Ave. 320 S. Boston Ave. 258 Genesee St. 777–14th St., N.W. 206 W. 4th St. 28 N. Wenatchee Ave. 40 Fourteenth St. 200 E. First St. 115 E. Main St. 288 Grove St. 56 N. Harrison St.
Tampa 6, Fla.Toledo 4, OhioTrenton 8, N. J.Tucson, Ariz.P.O. BoyTulsa 3, Okla.Utica 2, N. Y.Washington 5, D. C.Waterloo, IowaWenatchee, Wash.3Wheeling, W. Va.Wichita 2, Kan.Williamston, N. C.Worcester 5, Mass.York, Pa.	1202 Washington Bldg. 1206 North A St. 420 Madison Ave. 214 E. Hanover St. 214 E. Hanover St. 210 S. Boston Ave. 258 Genesee St. 777–14th St., N.W. 206 W. 4th St. 28 N. Wenatchee Ave. 40 Fourteenth St. 200 E. First St. 115 E. Main St. 288 Grove St.

Hawaii: American Factors, Ltd., P. O. Box 3230, Honolulu 1 Canada: Canadian General Electric Company, Ltd., Toronto ²³ INSTRUMENT DEPARTMENT, GENERAL ELECTRIC COMPANY, WEST LYNN, MASS.

SUPPLEMENT TO GEH-1539B & GEH-1539C

i

TYPES AB & DB AMMETERS AND VOLTMETERS

Use the dimension drawings in this supplement for Type DB-16 & -18 instruments having model numbers ending in "2" (Example: 8DB.....2) instead of Fig. 6, 7, 8, & 9 in Instructions GEH-1539B and -1539C.




Fig. 1. Dimensions of Type DB-16 ammeters, voltmeters, and ground detectors having model numbers ending in "2"







Fig. 2. Dimensions of Type DB-16 ammeters with rheostat for leadlength compensation, having model numbers ending in "2"


(over)





NOTE: THE LETTERS NEXT TO THE TERMINAL STUDS ARE FOR PURPOSES OF DIMENSIONAL LOCATION ONLY. FOR CONNECTIONS, SEE THE APPROPRIATE EXTERNAL CONNECTION DIAGRAM.





12-56 (25M)